

## INSTALLATION INSTRUCTIONS

### ARGO

FM-4407, FM-4411

# MODERN FORMS

**CAUTION: TO PREVENT ELECTRICAL SHOCK, ENSURE ELECTRICITY HAS BEEN TURNED OFF AT THE CIRCUIT BREAKER BEFORE BEGINNING.**

- Read all instructions before installing.
- System is intended for installation by a licensed electrician in accordance with the National Electrical Code (NEC) and local regulations.
- When handling the fixture, do not apply pressure to the LEDs. Hold the fixture by the base only.
- Retain installation instructions for future maintenance reference.

**WARNING:** All parts must be used as indicated in these instructions. This product is designed for use only with the supplied parts and/or accessories designated for use by Modern Forms. Substitution of parts or accessories not designated for use with this product by Modern Forms could result in personal injury or property damage, and will void the warranty. Contact an authorized dealer or the manufacturer if any parts are damaged or missing.

**MAINTENANCE NOTE:** Coastal conditions may cause mineral and residue build-up on the fixture. We recommend that customers in coastal areas clean all external surfaces of the fixture once every two weeks with a wet cloth.

**MISE EN GARDE:** Pour éviter tout choc électrique, assurez-vous que le disjoncteur soit mis hors tension avant de commencer.

- Lisez toutes les instructions avant l'installation.
- Le système doit être installé par un électricien licencié conformément au code national de l'électricité (NEC), et également aux règlements locaux.
- Lors de la manipulation du luminaire, n'appuyez pas sur les LED. Tenez-le uniquement par la base.

**ATTENTION:** Toutes les pièces doivent être utilisées comme indiqué dans ces instructions. Ce produit est conçu pour être utilisé seulement avec les pièces et/ou accessoires fournis pour être utilisés avec les produits Modern Forms. Remplacer des pièces ou accessoires non conçus pour ce produit Modern Forms pourrait causer des dommages corporels ou matériels et pourrait également causer l'annulation de la garantie. Veuillez contacter un revendeur autorisé ou le fabricant si des pièces manquent ou sont endommagées.

**NOTE D'ENTRETIEN:** Les conditions côtières peut causer une accumulation de minéraux et de résidu sur le luminaire. Nous recommandons aux clients qui résident dans les zones côtières de nettoyer toutes les surfaces externes du luminaire une fois toutes les deux semaines avec un chiffon humide.

## HARDWARE



Wire Connector  
Qty: 3 pcs  
P3



Junction Box Screw  
Qty: 2 pcs  
#8-32, \* 3/4"  
Stainless Steel

Modern Forms  
www.modernforms.com  
Phone (800) 526.2588 • Fax (800) 526.2585

Headquarters/Eastern Distribution Center  
44 Harbor Park Drive  
Port Washington, NY 11050

Central Distribution Center  
1600 Distribution Ct  
Lithia Springs, GA 30122

Western Distribution Center  
1750 Archibald Avenue  
Ontario, CA 91760

# INSTALLATION INSTRUCTIONS

## ARGO

FM-4407, FM-4411

# MODERN FORMS

### INSTALLATION

**Uses 3", 4", or a combination 3/0-4/0 junction box.**

1. Install the mounting plate to the junction box using the junction box screws provided.  
**NOTE:** Carefully align the slots on the mounting plate with the direction you want your fixture to be in to prevent uneven installation.
2. Provide electrical service according to the "National Electrical Code" or your local electrical code to the outlet box.
3. Clip the retention cable into the retention cable slot on the mounting plate to assist with wiring.
4. Connect supply wires to fixture wires and insulate with proper wire nuts. Connect incoming ground wire to mounting plate ground wire (green or bare). Connect incoming common wire to fixture common (white). Connect incoming hot wire to fixture black wire.
5. Raise the fixture to the junction box, guide the spring clips into the slots in the mounting plate and press the front of the fixture firmly in the center to lock the fixture in place.

**Note:** To ensure an easier installation, guide the spring clips through the slots on one side first before guiding the spring clips on the other side. Push all four clips in simultaneously.

Fig. 1

